Step	Step Title		Parts list	T	ools list	
Number		Quantity	Part name [1]	Quantity	Tool name	Remarks
1.1	Bottom Frame	8	Bracket 30	1	Square	Mark the front with the dot sticker.
		16	C-screw M6-14	1	Allen Key 5.0	Insert 8x T-nuts in each end of the profiles, 4x in each slot of the top surface of the profile.
		83	T-nut M6	1	Allen Key 4.0	'
		2	Profile 60-145			
		2	Profile 60-133			
		4	Wheels			
		3	Wire Fixer			
		1	Dot sticker			
		4	B-screw M6-16			
1.2	Preparing 30 profile	2	Profile 30-133	1	Allen Key 5.0	Don't tighten the screws yet for later adjustments.
		7	T-nut M6			
		6	C-screw M6-35			
		30	Washer M6			
		12	Washer M6 Large			
		18	Bearing			
		1	C-screw M6-12			
1.3	Attaching Profile 30 to Bottom Frame	4	Bracket 60	1	Allen Key 5.0	Align it to the Bottom Frame.
		16	T-nut M6			
		16	C-screw M6-14			
2.1	Fix Linear Guides Y	2	Linear Guide Y	1	Allen Key 3.0	
		2	Profile 60-133			
		42	T-nut M4			
		42	C-screw M4-16			
2.2	Fix X-axis Holders	1	X-axis Holder Right	1	Allen Key 5.0	
		1	X-axis Holder Left	1	Wrench 7	
		4	C-screw M4-16			
		4	C.screw M4-30			

Step			Parts list	T	ools list	Domestic
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
		4	Lock Nut M4			
2.3	Top Frame	2	Profile 60-145	1	Allen Key 5.0	Insert 8x T-nuts in each end of the profiles, 4x in each slot.
		1	Red Dot			
		4	Bracket 60			
		2	Bracket 30			
		24	C-screw M6-14			
		88	T-nut M6			
3	Vertical Profiles	4	Profile 60-133	1	Allen Key 3.0	Use clamps to align the profiles
		1	Prepared Bottom Frame (Step 1)	2	Clamp	Make sure the frame is precise
		1	Prepared Top Frame (Step 2)			
		32	Bracket 60			
		64	T-nut M6			
		128	C-screw M4-16			
4.1	Fix the Y-bearing support	2	Y-bearing Holder	1	Allen Key 5.0	
		2	Support Bearing Holder			
		6	C-screw M6-20			
		6	Washer M6			
		4	C-screw M6-16			
		10	T-nut M6			
4.2	Insert the Y-shafts	1	Y-shaft Right	1	Rubber Hammer	Insert each shaft into each the bearing holder, starting with the left.
		1	Y-shaft Left	1	Lubricant	Insert the Pulleys with the set screws turned inward.
		0	Dulley			Use a rubber hammer to insert the shafts into the Bearing Holder. The shafts
4.2	Fiv the V mater	2	Pulley	4	Allan 16 a. 5 C	should not protrude.
4.3	Fix the Y-motor	1	Y-motor	1	Allen Key 5.0	
		2	Coupler	1	Allen Key 4.0	

Step	SW.		Parts list	To	ools list	Damada
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
		4	C-screw M6-16	1	Wrench 8	
		1	Y-motor Holder			
		4	T-nut M6			
		4	C-screw M5-20			
		4	Lock Nut M5			
5.1	Y-pulleys Front	2	B-screw M6-12	1	Allen Key 4.0	Don't tighten the pulley. They should rotate freely.
		2	T-nut M6	1	Wrench 10	Don't tighten the brackets to the profile yet.
		2	Y Front Bracket			
		2	Y-pulley Front			
		6	Pulley Bearing			
		4	Washer M8 Big			
		4	Lock Nut M6			
5.2	Y-belt	2	Y-belt	1	Cutter	Tighten the screw of the front pulley bracket to tension the belt.
		8	Cable Tie			
6.1	Prepare Z-axis 1	4	Ball screw Z	1	Allen Key 5.0	First fix the Bolt Screw nut and the Bearing Block to the Middle Support.
		4	Linear Shaft	1	Allen Key 4.0	
		4	Middle Support	1	Wrench 8	
		4	Bearing Block			
		24	C-screw M6-50			
		24	Lock Nut M6			
		24	Washer M6			
		16	C-screw M5-35			
		16	Lock Nut M5			
		16	Washer M5			

Step	01 711		Parts list	To	ools list	Remarks
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	
6.2	Prepare Z-axis 2	4	Bottom Support	1	Rubber Hammer	Insert the Top Support into the Bolt screw and the shaft with a rubber hammer.
		4	Top Support	1	Lubricant	Insert the Bolt Screw and the shaft in the Bottom Support bearing with a rubber hammer.
		4	Z-pulley			Fix the Z-pulley in the lower end of the Bolt Screw.
7.1	Fix Z-axis	32	C-screw M6-35	1	Rubber Hammer	Fix the Bottom Suport to the frame first, then use a rubber hammer to insert the Top Support.
		32	C-screw M6-50	1	Lubricant	
				1	Allen Key 5.0	
7.2	Attach Z-motor	1	Z-motor support	1	Allen Key 4.0	
		1	Z-motor	1	Allen Key 5.0	
		1	Z-motor Pulley	1	Wrench 8	
		4	C-screw M5-20			
		4	Lock Nut M5			
		2	C-screw M6-16			
		2	T-nut M6			
7.3	Align the Middle Support	1	Z-belt	4	Template Block	Very critical step. If the Bed is skewed the Z-axis will lock.
				1	Rubber band	Use the Template Block in the 4 corners to align the distance between the Middle Support and the Bottom Support. Turn the Bolt Screw using big pliers with rubber inbetween to not damage the screw.
				1	water pump plier	Insert the belt and tension it by pushing the right-lower bearing with a key. Tighten the screw once the belt is tensioned.
8.1	Prepare the X-axis 1 - Back Fan	1	Back Fan	1	Allen Key 3.0	
		2	C-screw M4-25	1	Wrench 7	

Step	Chair Tible		Parts list	To	ools list	Domento
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
		2	Lock Nut M4			
		1	Back Fan Holder			
8.2	Prepare the X-axis 2 - Linear Guide	1	Linear Guide X	1	Allen Key 3.0	Fix the T-nut to the linear guide loosely and slide them into the profile.
		1	Profile 30-1200			The arrows of the linear guide should point down.
		19	C-screw M4-16			
		19	T-nut M4			
8.3	Prepare the X-axis 3 - Head Holder	1	Bed Leveling Sensor Holder	1	Allen Key 3.0	
		1	Bed Leveling Sensor	1	Allen Key 2.5	
		1	Head Holder	1	Wrench 5.5	
		4	C-screw M4-12			
		2	C-screw M3-10			
		2	Lock Nut M3			
		1	X-chain End Holder			
		2	C-screw M3-10			
8.4	Prepare the X-axis 4 - Extruder	1	Extruder Set			
		1	Heating Block			
		1	Filament Channel			
		1	Filament Tube			
		1	Fit Connector			
		1	E-motor			
8.5	Prepare the X-axis 5 - Right Pulley	1	X-pulley Right Holder	1	Allen Key 5.0	Don't tighten the pulley. They should rotate freely.
		1	X-pulley Right	1	Wrench 13	

Step	A. 1991		Parts list	Т	ools list	
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
		1	B-screw M8-70			
		6	Pulley Bearing			
		1	Washer M8 Big			
		1	Washer M8			
		1	Lock Nut M8			
		3	C-screw M6-14			
		3	T-nut M6			
8.6	Prepare the X-axis 6 - Chain Support	1	X-chain support	1	Allen Key 4.0	Don't tighten the screw for further adjustment.
		5	Countersunk Screw M6-12			Insert 2 T-nuts on the front slot of the profile, in the left side.
		7	T-nut M6			
9	Attach X-axis	1	Prepared X-axis (Step 8)		Allen Key 5.0	
		4	C-screw M6-16			
		4	T-nut M6			
10	Fix the X-chain	1	X-chain	1	Allen Key 2.5	Insert in the chain the E-motor Cable, Heating Block Cable, Heat Sensor Cable, Bed Leveling sensor, Fan
		2	C-screw M3-14	1	Allen Key 2.0	Connect the cables to their respective elements.
		1	B-screw M3-12	1	Wrench 5.5	
		3	Lock Nut M3			
		1	E-motor Cable			
		1	Heating Block Cable			
		1	Heat Sensor Cable			
		1	Bed Leveling Sensor Cable			
		1	Fan Cable			
11.1	Prepare the X-motor	1	X-motor	1	Allen Key 2.0	

Step	Step Title		Parts list	Т	ools list	
Number		Quantity	Part name [1]	Quantity	Tool name	Remarks
		1	X-motor Holder	1	Allen Key 5.0	
		1	X-pulley Left	1	Wrench 8	
		1	X-endstop Sensor Holder			
		3	C-screw M2.5-5			
		4	C-screw M5-20			
		4	Lock Nut M5			
11.2	Fix the X-motor	2	C-screw M6-16	1	Allen Key 5.0	
		1	X-endstop Sensor			
11.3	Fix X-belt	1	X-belt	1	Cutter	Use the extra screw on the right as a lever to tension the belt.
		4	Cable Tie	1	Allen Key 5.0	
12	Fix the Y-chain	1	Y-chain	1	Allen Key 4.0	Insert in the chain the cables from the X-chain, plus the motor and endstop sensor.
		1	Y-chain side support	1	Allen Key 3.0	The chains can be opened to insert the cables easily.
		5	T-nut M6	1	Wrench 7	
		4	B-screw M6-10			
		1	Wire Inserter			
		1	B-screw M6-12			
		1	B-screw M5-8			
		1	T-nut M5			
		3	C-screw M4-8			
		3	Lock Nut M4			
		1	X-endstop Cable			
13	Attach Y-endstop Sensor	1	Y-endstop Sensor	1	Allen Key 3.0	
		1	Y-endstop Sensor Holder			
		2	B-screw M5-12			
		2	T-nut M5			

Step	0, 77		Parts list	To	ools list	
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
14.1	Cable management 1 - front	1	Display Cable	1	Allen Key 4.0	Fix 2x Wire inserters on the back of the top front profiles and 2x on the back of right profile to hold the Display Cable in the profile slot.
		6	Wire Inserter	<u>'</u>	Allen Rey 4.0	the prome siot.
		6	B-screw M6-12			
		6	T-nut M6			
14.2	Cable management 2 - back top-left	2	Wire Inserter	1	Allen Key 4.0	
		5	Wire Fixer	1	Cutter	
		7	T-nut M6			
		2	B-screw M6-12			
		3	B-screw M6-16			
		1	Cable Wrapper			
		6	Cable ties			
14.3	Cable management 3 - back bottom-right	4	Wire Inserter	1	Allen Key 4.0	
		3	Wire Fixer	1	Cutter	
		7	T-nut M6			
		3	B-screw M6-16			
		4	B-screw M6-12			
		3	Cable Tie			
15	Align X-axis			2	Template or 2x identical objects	Use the templates or two identical objects as a reference to align the X-axis.
16.1	Prepare the Back Lower Panel 1	1	Back Lower Panel	1	Allen Key 3.0	Remove the foil from the panel.
		3	Motor Driver	1	Wrench 7	
		1	Extruder Motor Driver	1	Allen Key 4.0	
		8	C-screw M4-12	1	Wrench 8	
		1	Power Supply			
		4	C-screw M4-10			
		12	Lock Nut M4			
		1	Relay			

Step	Step Title		Parts list	To	ools list	Domonto
Number		Quantity	Part name [1]	Quantity	Tool name	Remarks
		2	C-screw M5-12			
		2	Lock Nut M5			
16.2	Prepare the Back Lower Panel 2	1	Power Switch	1	Allen key 2.5	Attach the Power Switch Cable to the Power Switch before fixing it.
		1	Power Plug	1	Screwdriver Phillips	Screw the body of the Power Switch first and then the knob.
		1	Power Switch Cable			
		2	B-screw M3-8			
16.3	Prepare the Back Lower Panel 3	3	Wire Duct 345	1	Allen Key 4.0	
		1	Wire Duct 520	1	Wrench 10	
		18	B-screw M6-12			
		18	Lock Nut M6			
		4	Cable Gland Small			
		4	Cable Gland Big			
16.4	Prepare the Back Lower Panel 4	1	Controller PCB	1	Alllen Key 2.5	
		1	Converter PCB	1	Wrench 5.5	
		4	Standoff M-F M3 10+6			
		4	Standoff M-F M3 20+6			
		8	Lock Nut M3			
		8	Plastic Screw M3-8			
17	Fix the Back Lower Panel	1	Prepared Back Lower Panel (Step 16)	1	Square	
		10	T-nut M6	1	Allen Key 4.0	
		10	Countersunk Screw M6-12			
18.1	Prepare the Bed 1	3	Profile 3060-1220	1	Allen Key 5.0	Mark the front with the dot sticker (longer profile).
		2	Profile 3060-1140			Don't tighten the screws yet for further adjustment.
		2	Profile 3060-525			
		1	Dot Sticker			

Step	Oton Title		Parts list	To	ools list	Remarks
Number	Step Title	Quantity	Part name [1]	Quantity	Tool name	Remarks
		32	Bracket 60			
		128	C-screw M6-14			
		128	T-nut M6			
18.2	Prepare the Bed 2	4	Corner Support	1	Allen Key 5.0	The longer side of the corner support should be on the front and back profiles.
		1	Center Support			
		77	C-screw M6-20			
		77	Washer M6			
		77	T-nut M6			
18.3	Prepare the Bed 3	1	Bed Plate	1	Allen Key 5.0	
		20	B-screw M8-20			
		20	Washer M8			
		20	T-nut M8			
18.4	Prepare the Bed 4	4	Heating Pad	1	Allen Key 4.0	The cables of the heating pads should be fixed in the middle profile and guided to the back of the machine.
		2	Cable Connector 3 Slots	1	Cutter	
		4	Wire Inserter			
		4	B-screw M6-12			
		7	Wire Fixer			
		7	B-screw M6-16			
		11	T-nut M6			
		7	Cable Tie			

Step	Step Title		Parts list	T	ools list	D
Number		Quantity	Part name [1]	Quantity	Tool name	Remarks
		1	Bed Heating Cable			
		1	Cable Wrapper			
19	Fix the Bed	1	Prepared Bed (Step 18)	1	Allen Key 10.0	
		4	C-screw M12-70	1	Wrench 19	
		4	Lock Nut M12			
		4	Washer M12			
20.1	Wiring 1	1	X-motor Logic Cable	1	Screwdriver slotted small	Some teeth of the wire duct can be removed to fit the cables.
		1	Y-motor Logic Cable	1	Screwdriver Phillips	Pass the cables through the correct cable glands.
		1	Z-motor Logic Cable			
		1	E-motor Logic Cable			
		1	Driver Power Cable			
20.2	Wiring 2	3	Endstop Jumper	1	Screwdriver slotted small	For the display cable, the lose wire is the reset, which should be pointing down
		1	Controller Power Cable	1	Screwdriver Phillips	
		1	Converter PCB Power Cable			
		1	Relay Power Cable			
20.3	Wiring 3 - AC	1	Relay AC Cable	1	Screwdriver Phillips	Fix the Earth on the frame
		1	Mains Cable	1	Screwdriver slotted small	
				1	Allen Key 5.0	
21	Fix Back Upper Panels	1	Back Top-right Panel	1	Allen Key 4.0	
		1	Back Top-left Panel			
		12	Countersunk Screw M6-8			
		12	T-nut M6			
22	Fix Side Panels	1	Right Side Right-Top Panel	1	Allen Key 5.0	
		1	Right Side Right-Bottom Panel			

Step	Step Title		Parts list	T	ools list	Demonto
Number		Quantity	Part name [1]	Quantity	Tool name	Remarks
		1	Left Side Left-Top Panel			
		1	Left Side Left-Bottom Panel			
		24	T-nut M6			
		24	Countersunk Screw M6-8			
23.1	Fix Front Panels [2]	1	Front Right-top Panel	1	Allen Key 4.0	
		1	Front Right-bottom Panel			
		1	Front Left-top Panel			
		1	Front Left-bottom Panel			
		40	Countersunk Screw M6-8			
		40	T-nut M6			
23.2	Fix Front Panels Connectors	2	Front Panels Connector	1	Allen Key 4.0	
		4	Countersunk Screw M6-8			
24	Install Display and USB Plug	1	Display with knob	1	Allen Key 2.0	Pull the knob cap out to attach the display.
		4	B-screw M3-8			
		4	Standoff M-F M3 6+6			
		4	Standoff F-F M3-6			
		1	USB Cable Inside			
		2	Pan Screw M2.5-6			
25	Fix Back Window	1	Back Window	1	Allen Key 4.0	Remove the foil from the panels.
		7	Lock Nut M6			
		7	Countersunk M6-6			
26	Fix Side Windows	2	Side Window	1	Allen Key 4.0	Remove the foil from the panels.
		24	Countersunk M6-6	1	Wrench 10	
		24	Lock Nut M6			
27	Install Electronics Cover	6	B-screw M5-8	1	Allen Key 3.0	Fix the window on the panel with double-sided tape.

Step Number	Step Title	Parts list		Tools list		
		Quantity	Part name [1]	Quantity	Tool name	Remarks
		1	Electronic Cover Panel	1	Cutter	
		1	Electronic Cover Window			
		1	Double-sided Tape			
28	Prepare the door	2	Door	1	Wrench 13	
		12	Lock Nut M8	1	Allen Key 5.0	
		8	Countersunk M8-12			
		4	Hinge			
		2	Handle			
		4	C-screw M8-20			
29	Fix the window / doors	2	Prepared Doors (step 28)	1	Wrench 13	
		8	Lock Nut M8	1	Allen Key 5.0	
		8	Countersunk M8-12			
		4	Door Magnet			
		2	Angle Profile			
30	Attach the spool holder	4	B-screw M5-12	1	Allen Key 3.0	
		10	T-nut M5			
		2	Bracket 20			
		2	Profile 30-150			
		1	Spool Axis			
		2	Spool Axis Stopper			
		2	Spool Axis Holder			
		6	B-screw M5-12			